

HSG736227I

Gas Range Cooker
White



Type: Full Gas Range Cooker

Pan Supports: Cast Iron Pan Support

Range Cooker Dimensions (HxWxD): 84.6-88.0 cm x 89.8 cm x 60.0 cm

Oven Capacity: 112 Litres

3 Oven Cooking Functions: Gas grill, Gas bottom heat, Rotisserie

Accessories: 1 x enamel baking tray ,1 x rotary spit, 1 x nozzle set for natural gas, 1 x cross support for espresso, 1 x grid,

The gas Range Cooker with gas hob: enjoy the benefits of gas when cooking and baking.



Closed Door Grilling

Retains heat and odors within the cooker and reduces your cooking time.



Full Safety

Safety system that automatically cuts off the gas supply to your burner or full safety oven, if the flame goes out for any reason.



Full Glass Inner Door

Experience effortless oven cleaning with the Bosch cooker full glass door!



Cast Iron Pan Support

Provides extra support for your heavier pots and pans.



Catalytic Cleaning: Side Liners

Oven cleans itself thanks to catalytic panels while cleaning.