

Series | 8 HSG958DB1S

Built-In Electric Oven
60 x 60 cm, Black



Connection Rating: 3600 W

Dimensions (HxWxD): 59.5 x 59.4 x 54.8 cm

Min. Required Niche Size for installation (HxWxD): 58.5-59.5 x 56.0-56.8 x 55.0 cm

Oven Net Capacity: 71 Litres

Combi-steam oven with 24 heating methods: 4D hotair, Conventional heat, Hot air grilling, Full width grill, Half width grill, Pizza setting, Bottom heat, Intensive heat, Low temperature cooking, Preheating, Desiccation, Keep warm, Hotair gentle, Conventional heat gentle, Air fry, Steam, Regeneration with steam, Fermentation with steam, Defrost with steam, sous-vide cooking, hotair grilling + steam, warming + steam, 4D hotair + steam, Top/bottom heat + steam

Fast Preheat: Yes

Integrated Cleaning: Eco Clean Direct coating of ceiling, back panel, side liners + Hydrolytic

Accessories: 1 x grid, 1 x universal pan, 1 x steam container, punched, size XL, 1 x sponge, 1 x steam container, punched, size M, 1 x steam container, unpunched, size M, 1 x air fry & grill tray

The built-in oven with PerfectBake and PerfectRoast: you get perfect baking and roasting results – automatically.



Steam Technology

Steam Function Plus 120°C - your dishes retain even more of their vitamins and nutrients and are done faster.



Sensors

Baking sensor with time prediction, roastingSensor Plus with time prediction.



PerfectBake Plus

Regulates baking settings and tells you exactly when to remove dishes from the oven.



PerfectRoast Plus

Is a meat probe that uses three measuring points to check the temperature.



Air Fry Function

Allows you to cook crispy, delicious food with less oil than traditional frying methods



4D Hotair

Even heat distribution for perfect results – on any level.



Hydrolytic Cleaning Program

Less cleaning effort thanks to the new cleaning option, which can be especially used for cleaning of light soiling.



Eco Clean Direct

EcoClean Direct automatically cleans your oven while you bake or roast. Saves you time and energy - simple and smart. To remove substantial residues, simply activate the EcoClean Direct cleaning programme.



Flap door with Soft Open and Soft Close

The oven door opens and closes especially gently and quietly.



2-stage telescopic rails

For safe, easy insertion and removal of baking trays.