


PXX375FB1E

Flex Induction Cooktop
30 cm, Ceramic Glass Black



BOSCH



Dimensions (HxWxD): 5.1 x 30.6 x 52.7 cm

Min. Required Niche Size for installation (HxWxD): 51 x 27.0 x 49.0-50.0 cm

Connection Rating: 3700 W

17 power levels: precisely adapt the heat with 17 power levels (9 main levels and 8 intermediate levels).

Number of Cooking Zones: 2

Environment+Safety:

A) Residual heat indicator (2 stage): indicates which cooking zones are still hot or warm.

B) Childproof lock: prevent unintended activation of the hob.

C) Main Switch: switch off all cooking zones at the touch of a button.

D) Safety switch-off: for safety reasons, heating stops after a preset time without interaction.

E) Energy consumption display: shows the electricity consumption of the last cooking process.

The induction hob of the Domino programme: cook quickly, safely and cleanly with low energy consumption.



DirectSelect Touch Control

Directly control the power with imprinted touch bar.



FlexInduction

More flexibility on your hob for large pots and pans.



Power Boost

Up to 50% faster heating compared to highest power level.



Restart

In case of unintentional switch-off, restore all previous settings by switching on the hob again within 4 seconds.



Timer with Switch-off Function

Turns off the assigned cooking zone after the set time.