

# SMS6HMW27Q

Free-standing dishwasher  
60 cm, White



**BOSCH**

**Type:** Freestanding Dishwasher

**Dimensions in cm (H X W X D):** 84.5 x 60 x 60

**Place of setting:** 13

**Racks:** 3

**Sprinklers:** 3

**7 Programs:** : Eco 50 °C, Auto 45-65 °C, Intensive 70 °C, Quick L 65 °C, Quick S 45 °C, Delicate 40°C, Silence Program 50 °C (Night Program)

**6 Options:** Remote Start, Intensive Zone, Half Load, Hygiene+, SpeedPerfect+, Machine Care

**Our ActiveWater 60: Especially good for the environment and your budget, thanks to very high energy efficiency.**



**Silence Plus and Silence Program**

Pleasantly quiet at 44 dB, more so with the Silence program.



**ActiveWater 60**

Especially good for the environment and your budget, thanks to very high energy efficiency.



**EcoSilence Drive™**

Especially energy saving and silent in operation with a particularly high life span.



**VarioDrawer**

There is more room in the third level for greater flexibility at stacking time.



**AquaStop**

Bosch's safety system in case of water damage.



**Rackmatic**

Height-adjustable dishwasher basket for tall items.